



# TACHPAK<sup>®</sup> 10 & 30 Digital Process Tachometer

Part Number Series T77510 & T77530

> C€ RoHS

#### TACHPAK 30 Key Features:

- Wide range of AC or DC power (12-30 Vdc, 80-264Vac 50-60Hz)
- Greatly improved instrument accuracy, processing speed and response time.
- Frequency, period or counter modes.
- User-defined inputs for logic level, averaging, alarm set points and hysteresis,
- Signal normalization and math functions allow mathematical manipulation of input signals. Results can be displayed along with user-defined units.
- Accepts sinusoidal and square wave inputs as found in variable reluctance and digital output speed sensors.
- Accepts bi-directional sensor inputs and will decode quadrature or direction signal logic
- 2 solid state relays (fast response time) and 2 mechanical relays (high power)
- Analog output: 0-20mA, 4-20mA, -20-0-(+) 20mA (can be used with bi-directional sensor)
- Two programming methods: Front panel on display or USB2.0 connectivity to PC / Windowsbased **TACHLINK**.
- Utility RS485 communication allows full TACHLINK function over longer distances (up to 8000 ft)
- Drives up to 8 remote displays (TACHTROL plus). A single display can be up to 1000 ft away with a simple RJ11 (phone jack) connection. Longer runs, cable type and number of displays will affect distance.
- Security mode protects unauthorized access for programming or alarm resets (through display or **TACHLINK**)
- Mounts to DIN rail. Power can be applied through special DIN bus when used with **AI-TEK** power supply.
- Environmentally hardened for temperature, vibration and shock. EMC / CE compliant to current BS/ EN directives.
- Designed and manufactured compliant with RoHS.

## TACHPAK 10 Key Features:

• Same as TACHPAK 30 but excludes solid state relays, analog output and utility RS485

## Programming Features:

Programming has been greatly simplified and can be accomplished by 2 different methods. Many configurable attributes have been added to improve flexibility and function.

• Display front panel: **TACHTROL** 10 and 30 can be programmed through the integrated display/membrane panel. **TACHPAK** 10 and 30 can also be programmed in the same manner with the addition of a **TACHTROL plus** remote display. In either case programming is accomplished

#### **Programming Features continued:**

by navigating through a series of nested menus. In the case of tachometer instruments embedded in explosion proof or **NEMA 4X** enclosures, remote access solves the problem of programming by making use of an IR link to allow full front panel control via a hand-held remote.

 TACHLINK<sup>®</sup>: PC / Windows-based custom software allows the user to program all configurable attributes of TACHPAK and TACHTROL by PC via a USB2.0 or RS485 connection. In addition, the PC can be used to display data, perform security functions, diagnostics, analog output calibration and real-time data logging; all available through the TACHLINK.

1

#### Applications:

- Fast response overspeed shutdown
- Petrochemical production applications
- Pump or generator alarm
- Low speed switching
- Start-up, over/under speed switching
- Textile production
  applications
- Machine control
- Paper & pulp production
- Turbine speed control
- Food processing
- Conveyor alarms
- Printing industry
- Metal production
- Mining applications
- Test labs
- Generator set
- Broken or slipping
  belt drives

| oou  |                 | 4.15 [105.3 mm] —   |   |
|------|-----------------|---|---|
| tion |                 |   |   |
| arm  | 1.78 [45.2 mm]  | EHOTE DISPLAY USB<br>- POWER<br>- | RENOTE DISPLAY USS<br>-POWER<br>TACHPAK <sup>40</sup> |
|      |                 | TACHPAK 30  | TACHPAK 10  |
|      |                 | COVERS R  | EMOVED FOR CLARITY                                    |
| ion  | 4.51 [114.5 mm] | TACHPAR <sup>20</sup><br>Tertumber 177530-10<br>Tertumber 177530-10<br>Tertumber 177530-10<br>Tertumber 177530-10<br>Tertumber 100400<br>Tertumber 1004000<br>Tertumber 100400<br>Tertumber 1004000<br>Tertumber 1004000<br>Tertumber 1004000<br>Tertumber 1004000<br>Tertumber 1004000   | -IDENTIFICATION<br>-SPRING CLIP                       |

4 1E [10E 2 mm]

. 1

| Ordering<br>P/N | Input Power          | Enclosure       | Net Weight<br>(lbs.) |
|-----------------|----------------------|-----------------|----------------------|
| T77510-10       | 80-264 Vac/12-30 Vdc | Standard        | 0.6                  |
| T77510-40       | 80-264 Vac/12-30 Vdc | NEMA 4X         | 3.4                  |
| T77510-70       | 80-264 Vac/12-30 Vdc | Explosion Proof | 24.0                 |
| T77530-10       | 80-264 Vac/12-30 Vdc | Standard        | 0.7                  |
| T77530-40       | 80-264 Vac/12-30 Vdc | NEMA-4X         | 3.5                  |
| T77530-70       | 80-264 Vac/12-30 Vdc | Explosion Proof | 24.0                 |

| Table 2: Connection Information |  |            |            |  |  |  |  |  |
|---------------------------------|--|------------|------------|--|--|--|--|--|
| Terminal                        | Pin #  | TACHPAK 30 | TACHPAK 10 |  |  |  |  |  |
| Block                           |  |            |            |  |  |  |  |  |
| Remote                          | Use RJ11 type connector. No individual breakout of pins. |            |            |  |  |  |  |  |
| Display                         |  |            |            |  |  |  |  |  |
| USB                             | Use USB "B" type connector. No individual breakout of    |            |            |  |  |  |  |  |
|                                 | pins.  |            |            |  |  |  |  |  |
|                                 | 1,5  | GND        |            |  |  |  |  |  |
|                                 | 2  | Tx -       |            |  |  |  |  |  |
| RS485                           | 3  | Rx -       | Not        |  |  |  |  |  |
| DB9                             | 6  | Tx +       | Available  |  |  |  |  |  |
|                                 | 7  | Rx +       |            |  |  |  |  |  |
|                                 | 4,8,9  | Not Used   |            |  |  |  |  |  |

| Table 3: Connection Information |        |                         |                 |  |  |  |  |
|---------------------------------|--------|-------------------------|-----------------|--|--|--|--|
| Terminal<br>Block               | Pin #  | TACHPAK 30              | TACHPAK 10      |  |  |  |  |
|                                 | 1      | Input Com               | Input Com       |  |  |  |  |
|                                 | 2      | A Sig                   | A Sig           |  |  |  |  |
| TB1                             | 3      | B Sig                   | B Sig           |  |  |  |  |
|                                 | 4<br>5 | Direction Input         | Direction Input |  |  |  |  |
|                                 | 5      | Verify -                | Verify -        |  |  |  |  |
|                                 | 6      | Verify +                | Verify +        |  |  |  |  |
| TB2                             | 7      | Reset -                 | Reset -         |  |  |  |  |
|                                 | 8      | Reset +                 | Reset +         |  |  |  |  |
|                                 | 9      | Analog Out +            |                 |  |  |  |  |
|                                 | 10     | Analog Shield           | Not             |  |  |  |  |
| TB4                             | 11     | Analog Out -            | Available       |  |  |  |  |
|                                 | 12     | Not Used                |                 |  |  |  |  |
|                                 | 13     | In GND                  | In GND          |  |  |  |  |
|                                 | 14     | 12-30 Volt In           | 12-30 Volt In   |  |  |  |  |
| TB3                             | 15     | +12 Vdc Out             | +12 Vdc Out     |  |  |  |  |
|                                 | 16     | Out GND                 | Out GND         |  |  |  |  |
|                                 | 17     | Relay 1 Com             | Relay 1 Com     |  |  |  |  |
|                                 | 18     | Relay 1 N.C.            | Relay 1 N.C.    |  |  |  |  |
| TB5                             | 19     | Relay 1 N.O.            | Relay 1 N.O.    |  |  |  |  |
|                                 | 20     | Not Used                | Not Used        |  |  |  |  |
|                                 | 21     | Relay 2 Com             | Relay 2 Com     |  |  |  |  |
|                                 | 22     | Relay 2 N.C.            | Relay 2 N.C.    |  |  |  |  |
| TB6                             | 23     | Relay 2 N.O.            | Relay 2 N.O.    |  |  |  |  |
|                                 | 24     | Not Used                | Not Used        |  |  |  |  |
|                                 | 25     | AC/Earth Gnd            | AC/Earth Gnd    |  |  |  |  |
|                                 | 26     | Not Used                | Not Used        |  |  |  |  |
| TB8                             | 27     | AC Hot                  | AC Hot          |  |  |  |  |
|                                 | 28     | AC Neutral              | AC Neutral      |  |  |  |  |
|                                 | 29     | Digital 1 (no polarity) |                 |  |  |  |  |
|                                 | 30     | Digital 1 (no polarity) | Not             |  |  |  |  |
| TB7                             | 31     | Digital 2 (no polarity) | Available       |  |  |  |  |
|                                 | 32     | Digital 2 (no polarity) |                 |  |  |  |  |

Connection to 12-30 Volt In is also available on the bottom of **TACHPAK 10 & 30**. A special DIN rail power bus adapter is available as an accessory and works with the accessory power supply.